ezcap

VHSDigi2

manual



Model: ezcap181P Ver：M181P20250723

Thanks for purchasing ezcap181P VHSDigi2 VHS Digitizer. Please read this manual before use and keep it in a safe place for future reference.

You can use this machine:

Convert VHS and all Composite video to digital file, and save in USB flash drive.

Overview

In the Box

ezcap181P VHSDigi2 x1, Manual x1, USB A to C power cable x1

Product Overview and Connections



1. VIDEO AUDIO IN – RCA Composite video and L/R audio input from video source device such as VHS. Yellow = video, white = audio left channel, red = audio right

channel.(The video source device should include the video cable, usually it is the 3RCA to 3RCA male cable or 3.5mm to 3RCA male video cable)

2. HDMI OUT – Connect to TV or monitor to display video with HDMI Cable. (HDMI Cable is not included.)
3. USB – Plug USB drive to save recorded video files.
4. DC – Connect to 5V DC power with USB-C to USB-A cable. (Power adapter is not included)
5. Record Button – Press to record video, press again to stop and save file.
6. REC LED –BLUE light will be on when device is ready, and GREEN light will be on when press REC button to start recording.
7. PWR LED – RED light will be on after connect power DC.

Note: Supports FAT32 and exFAT formats of USB flash drive, does not support NTFS.

Start Work

Record Video

You will preview the video on TV or monitor when all connections are ready, and BLUE light is on, press **RECORD button** to record video, and REC GREEN light will be on, it means it is recording. Press **RECORD button** again to stop recording and save to USB flash drive.

Recorded Files

You can take off USB drive to connect to your computer to check the recorded video files after you stopped recording. It is named as REC_Video_00000001.mp4.

Every record/stop operation will create a different recording file: REC_Video_00000001, REC_Video_00000002, REC_Video_00000003… and so on.

The max size per file will be about 4GB for FAT format USB drive, and about 32GB for exFAT format USB drive, when you record a video up to the capacity, ezcap181P VHSDigi2 will partition it in more than one file, for example: If you record a longtime video by one click recording, you will see 2 or more files.

Specifications

Interface	USB 2.0
Video Input	RCA Composite video
Audio Input	RCA analog L/R audio
VideoOutput	HDMI
Audio Output	HDMI
User Interface	RECORD/STOP button, Power and record indicator LED.
Storage Media	USB drive, supports FAT32 and exFAT, and NTFS is not supported.
Record Format	.mp4
Record Quality	1280 x 720p@60fps (Old version records video into 720x480 or 720x576)

Record File	Max single file is about 4GB for FAT32 format, and 32GB for exFAT format
Power Supply	USB-C to USB-A power cable (Not include 5V2A power adapter)
Dimensions	76(L) × 81(W) × 23(H) mm
Weight	70g

视频录制盒

说明书



产品型号：ezcap181P

感谢您购买 ezcap181P VHSDigi2 AV 录制盒。 请在使用前阅读本手册并将其保存在安全的地方以备将来参考。 你可以使用这台机器： 将 VHS 和所有复合视频转换为数字视频文件，保存在 U 盘里。

概览

包装内容

ezcap181P VHSDigi2 视频录制盒 x1，说明书 x1, Type-C 转 USB 电源线 x1

产品概览和连接图



1. VIDEO AUDIO IN – RCA 复合视频和左右声道输入，用视频线把视频源设备(比如老式放像机或摄像机)的视频输出与该接口连接。黄色 = 视频，白色 = 左声道，红色= 右声道。(视频源设备会自带视频输出线，通常为一根 3RCA 对 3RCA 公头视频线或 3.5mm 对 3RCA 公头视频线)
2. HDMI OUT – HDMI 输出，用 HDMI 线连接到电视机或显示器以显示视频。
3. USB – U 盘接口，插入 U 盘以存储录制的视频文件。

4. DC – 供电接口，用 Type-C 线连接 5V/2A 适配器供电。(不包括电源适配器)

5. Record Button –录制/停止按键，按下开始录制，再次按下停止录制并保存文件。

6. 录制指示灯–设备准备好了蓝色指示灯亮起，按下录制键开始录制时绿色录制指示灯亮起。

7. 电源指示灯– 红色电源指示灯，连接电源后亮起。

注：U 盘支持 FAT32 和 exFAT 格式，不支持 NTFS。

开始使用

录制视频

当您准备好以上所有连接后，你会在电视或显示器上看到视频，同时蓝色指示灯亮起。此时按下**录制按键**开始录制，绿色录制指示灯亮起，表示设备正在录制中。再次按下**录制按键**停止录制，同时录制文件被保存于 U 盘中。

录制文件

停止录制后，您可以拔出 U 盘或 TF 卡并连接到电脑以查看录制文件，文件名为 REC_Video_00000001.mp4。每次录制/停止的操作都会产生一个不同文件名的视频文件： REC_Video_00000001，REC_Video_00000002，REC_Video_00000003。

FAT32 格式 U 盘录制单个文件最大约 4GB，exFAT 格式 U 盘录制单个文件最大约 32GB。当你录制单个视频达到该容量，则 ezcap181P VHSDigi2 视频录制盒会保存一个文件，同时新建另外一个文件。举例：如果你按一次录制按键以录制一个长时间视频，会得到两个或更多视频文件。

规格参数

界面	USB 2.0
视频输入	RCA 复合视频
音频输入	RCA 模拟左右声道
视频输出	HDMI
音频输出	HDMI
用户界面	录制/停止按键，电源指示灯，录制指示灯。
存储媒介	U 盘，支持 FAT32 和 exFAT 格式，不支持 NTFS 格式。
录制格式	.mp4
录制质量	1280 x 720p@60fps (旧版本录制格式为 720x480 或 720x576)
录制文件	FAT32 格式单个文件最大约 4GB，exFAT 格式最大约 32GB。
电源适配器	Type-C USB 电源线 （不包括 5V2A 电源适配器）
产品尺寸	76(长) × 81(宽) × 23(厚) 毫米
产品重量	70 克